



# 148GTL-F CIRCUIT DIAGRAM



Notes:  
 1. Resistance values are shown in Ohms unless otherwise noted. (K=Kilo Ohm; M=Meg Ohm)  
 2. Capacitance values are indicated in Farads unless otherwise noted. (pF=Micro Farad; PP=Micro-micro Farad.)  
 3. Capacitance values are shown in Henry (H=Micro Henry)  
 4. Circuit and components are subject to change without notice.



TITLE: 148GTL-F CIRCUIT DIAGRAM FOR COBRA					
PREPARED BY: XW RENG	CHECKED BY:	APPROVED BY:	SIZE: A1	VER: 01	SHEET: 1 OF 2
UPDATED: JUN./27/2006	DATE:	DATE:			