


CIRCUIT DIAGRAM FOR COBRA 142GTL



NOTES: 1. PARTS LISTED IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE.
 2. RESISTOR VALUES ARE IN OHMS UNLESS OTHERWISE SPECIFIED.
 3. CAPACITOR VALUES ARE IN MICROFARADS UNLESS OTHERWISE SPECIFIED.
 4. CONNECTIONS IDENTIFIED BY CIRCLED LETTERS ARE TO MATCH SHOWN MODEL.

