



BILL OF MATERIAL FOR COBRA 55XLR

CIRCUIT SYMBOL	DESCRIPTION	DYNAMSCAN PART NO.
IC-101	IC, TRANSISTORS & DIODES	
IC-102	IC, TRANSISTORS & DIODES	
IC-3104	IC, TRANSISTORS & DIODES	
IC-4	IC, TRANSISTORS & DIODES	
IC-5	IC, TRANSISTORS & DIODES	
IC-1	IC, TRANSISTORS & DIODES	
IC-2	IC, TRANSISTORS & DIODES	
TR-102	TR, TRANSISTORS	
TR-109	TR, TRANSISTORS	
TR-116	TR, TRANSISTORS	
TR-103, 104, 105	TR, TRANSISTORS	
TR-108	TR, TRANSISTORS	
TR-109	TR, TRANSISTORS	
TR-110, 111, 112	TR, TRANSISTORS	
TR-113, 114, 115	TR, TRANSISTORS	
TR-118, 119	TR, TRANSISTORS	
TR-124	TR, TRANSISTORS	
TR-3.5	TR, TRANSISTORS	
TR-6	TR, TRANSISTORS	
D-1	Diode Silicon Rectifier, 15Z790WT	151-978-9-001
D-101, 109, 116	Diode Silicon Switching, 15Z471 X	151-978-9-001
D-102, 103, 104	Diode Silicon, 1N602AM	150-014-9-001
D-108, 106, 112, 114, 115, 117, 118, 204, 205, 301, 34, 5, 6	Diode Silicon, 15Z076	151-967-9-001
D-271	Diode, Zener 05Z-9-1H	152-085-9-001
D-501, 502, 503, 504, 505	Diode, Zener RDS-2TC	152-085-9-002
	L.E.D. Strip 1/4B, Tape & Stereo Indicator	158-019-9-001
COILS & TRANSFORMER		
L-101	Coil, LA-029	060-023-9-001
L-102	Coil, LA-184	060-024-9-001
L-103, 114	Coil, LA-183	060-024-9-001
L-106	Coil, LA-183	060-028-9-001
L-108	Coil, LA-184	060-024-9-005
L-112	Coil, LA-185	060-024-9-006
L-111	Coil, LA-185	060-024-9-010
L-110	Coil, LC-051	041-094-9-001
L-108	Coil, LC-020	044-033-9-002
L-107	Coil, LC-020	044-048-9-001
	Coil, LE-008	044-032-9-001

CIRCUIT SYMBOL	DESCRIPTION	DYNAMSCAN PART NO.
L-117	Coil, LA-189	060-024-9-008
L-116	Coil, LA-182	060-024-9-003
L-11	Coil, LB-098	046-021-9-001
L-6	Coil, LB-098	046-021-9-002
L-8	Coil, LB-098	046-021-9-003
L-3, 7	Coil, LB-089	044-048-9-002
L-2, 119	Coil, LB-089	044-048-9-004
L-2	Inductor, LZ-002	041-082-9-003
L-10	Inductor, LZ-001	041-082-9-002
L-118	Inductor, LZ-001	041-082-9-001
L-121	Core Bead, LD-057	044-048-9-003
CH-1	Inductor, TF-017	042-014-9-001
TF-1	Modulation Transformer, TF-119	051-037-9-001
VARIABLE RESISTORS		
VR-5	Resistor, Semi-Fixed RV-189	008-323-9-001
VR-108	Resistor, Semi-Fixed RV-189	008-316-9-004
VR-3	Resistor, Semi-Fixed RV-189	008-316-9-003
VR-1.2	Resistor, Semi-Fixed RV-189	008-331-9-001
VR-102A + VR-102B + VR-102A + VR-102B + S1 + S2	Resistor, Variable RV-279	008-316-9-002
VR-401A + VR-401B	Resistor, Variable RV-277	008-331-9-003
	Resistor, Variable RV-276	008-330-9-005
	Resistor, Variable RV-275	008-330-9-006
COILS & TRANSFORMER (Continued)		
L-117	Coil, LA-189	060-024-9-008
L-116	Coil, LA-182	060-024-9-003
L-11	Coil, LB-098	046-021-9-001
L-6	Coil, LB-098	046-021-9-002
L-8	Coil, LB-098	046-021-9-003
L-3, 7	Coil, LB-089	044-048-9-002
L-2, 119	Coil, LB-089	044-048-9-004
L-2	Inductor, LZ-002	041-082-9-003
L-10	Inductor, LZ-001	041-082-9-002
L-118	Inductor, LZ-001	041-082-9-001
L-121	Core Bead, LD-057	044-048-9-003
CH-1	Inductor, TF-017	042-014-9-001
TF-1	Modulation Transformer, TF-119	051-037-9-001
RESISTORS		
R-234	Resistor, Carbon Film 2.7 ohm ±5% 1/8W	002-108-5-279
R-57	Resistor, Carbon Film 4.7 ohm ±5% 1/8W	002-108-5-479
R-215	Resistor, Carbon Film 33 ohm ±5% 1/8W	002-108-5-330
R-13	Resistor, Carbon Film 68 ohm ±5% 1/8W	002-108-5-680
R-221, 271, 285	Resistor, Carbon Film 100 ohm ±5% 1/8W	002-108-5-101
R-6, 60, 205, 207, 212, 217, R-21	Resistor, Carbon Film 180 ohm ±5% 1/8W	002-108-5-181
R-60, 205, 207, 212, 217, R-21	Resistor, Carbon Film 220 ohm ±5% 1/8W	002-108-5-221
R-20	Resistor, Carbon Film 330 ohm ±5% 1/8W	002-108-5-331
R-26, 301	Resistor, Carbon Film 390 ohm ±5% 1/8W	002-108-5-391
R-4, 52, 55	Resistor, Carbon Film 470 ohm ±5% 1/8W	002-108-5-471
R-114, 115, 267, 270	Resistor, Carbon Film 560 ohm ±5% 1/8W	002-108-5-471
R-25, 269, 303	Resistor, Carbon Film 680 ohm ±5% 1/8W	002-108-5-681
R-12, 210, 281	Resistor, Carbon Film 820 ohm ±5% 1/8W	002-108-5-820
R-2, 14, 24, 45, 62, 204, R-216, 275, 289, 201	Resistor, Carbon Film 1K ohm ±5% 1/8W	002-108-5-102
R-49, 213	Resistor, Carbon Film 1.5K ohm ±5% 1/8W	002-108-5-152
R-112, 230, 238	Resistor, Carbon Film 2.2K ohm ±5% 1/8W	002-108-5-222
R-17, 30, 51, 54, 218, 249, R-272	Resistor, Carbon Film 3.3K ohm ±5% 1/8W	002-108-5-332
R-1, 5, 16	Resistor, Carbon Film 3.9K ohm ±5% 1/8W	002-108-5-392

CIRCUIT SYMBOL	DESCRIPTION	DYNAMSCAN PART NO.
C-263, 264	Capacitor, Tantalum, 2.2uF	027-031-9-001
C-102, 103, 109, 110	Capacitor, Tantalum, 4.7uF	027-032-9-001
C-312	Capacitor, Tantalum, 4.7uF	027-031-9-002
C-49, 50, 308	Capacitor, Aluminum Solid, 0.22uF	022-158-9-001
C-51	Capacitor, Aluminum Solid, 0.47uF	022-161-9-002
C-53	Capacitor, Polyethylene Film, 470pF	030-042-9-002
C-21, 48, 220, 250, 253, C-254, 286	Capacitor, Electrolytic, 1uF	022-157-9-002
C-262, 69, 62	Capacitor, Electrolytic, 2.2uF	022-158-9-002
C-248, 255	Capacitor, Electrolytic, 4.7uF	022-157-9-003
C-35, 45, 106, 108	Capacitor, Electrolytic, 10uF	022-157-9-001
C-104, 117, 251, 318	Capacitor, Electrolytic, 22uF	022-163-9-001
C-42, 56, 118, 119, 123, C-42, 56, 118, 119, 123, 124, 302, 303, 291	Capacitor, Electrolytic, 47uF	022-164-9-001
C-80	Capacitor, Electrolytic, 47uF	022-164-9-002
C-59, 64, 69, 128, 129, C-59, 64, 69, 128, 129, 293, 297	Capacitor, Electrolytic, 100uF	022-157-9-008
C-257	Capacitor, Electrolytic, 220uF	022-157-9-009
C-247, 286, 306, 307	Capacitor, Electrolytic, 330uF	022-163-9-002
C-101	Capacitor, Electrolytic, 470uF	022-164-9-003
C-122, 127	Capacitor, Electrolytic, 1000uF	022-160-9-001
C-259, 271	Capacitor, Polyester Film, 0.0022uF	026-122-9-001
C-27, 30, 222	Capacitor, Polyester Film, 0.0022uF	026-122-9-001
C-30, 301	Capacitor, Polyester Film, 0.0022uF	026-122-9-001
C-287, 298	Capacitor, Polyester Film, 0.0022uF	026-122-9-001
C-38, 105, 107	Capacitor, Polyester Film, 0.01uF	025-121-9-002
C-33, 54, 55, 63, 235, 284, 285	Capacitor, Polyester Film, 0.022uF	025-121-9-003
C-36, 37, 43, 288, 289	Capacitor, Polyester Film, 0.033uF	025-121-9-004
C-82	Capacitor, Polyester Film, 0.047uF	025-121-9-005
C-204, 294	Capacitor, Polyester Film, 0.089uF	026-126-9-001
C-243, 285	Capacitor, Ceramic Disk, 1.5pF	020-180-9-001
C-11, 285	Capacitor, Ceramic Disk, 3pF	020-187-9-001
C-251, 276	Capacitor, Ceramic Disk, 4.7pF	020-180-9-003
C-22, 270, 272, 273	Capacitor, Ceramic Disk, 22pF	020-180-9-005
C-68	Capacitor, Ceramic Disk, 27pF	020-180-9-006
C-229	Capacitor, Ceramic Disk, 39pF	020-180-9-007
C-233	Capacitor, Ceramic Disk, 68pF	020-180-9-015
C-279	Capacitor, Ceramic Disk, 100pF	020-180-9-014
C-239	Capacitor, Ceramic Disk, 150pF	020-180-9-016
C-231, 226	Capacitor, Ceramic Disk, 220pF	020-180-9-019
C-253, 245	Capacitor, Ceramic Disk, 270pF	020-180-9-011
C-277	Capacitor, Ceramic Disk, 390pF	020-180-9-017
C-294	Capacitor, Ceramic Disk, 0.0001uF	020-190-9-012
C-218, 219, 299, 318	Capacitor, Ceramic Disk, 0.0001uF	020-190-9-014

CIRCUIT SYMBOL	DESCRIPTION	DYNAMSCAN PART NO.
M-401, PL-401	Master, MT-087 Lamp Bulb	320-092-9-001
P-21, 22, 23	Test Point Terminal, TP-033	757-037-9-001
CN2-P, CN11-P	Plug 2 pins, PG-044	523-209-9-004
CN3-P	Plug 3 pins, PG-039	523-210-9-001
CN4-P	Plug 4 pins, PG-043	523-210-9-002
CN101-P	Plug 6 pins, PG-038	523-204-9-002
CN102-P	Plug 7 pins, PG-038	523-209-9-001
TP1, 12, 13, 14, 15, 18	Remote Control Microphone, MK-006	523-209-9-001
S1, S2, S6, S7, +S8 + S9, S10	Test Point Terminal, TP-029	523-209-9-001
LI1A, LI1B + LIC + LI2A + LI2B + LI2C	Push Button Switch	069-039-9-001
MH401A + MH401B + MH401 + S401 + S402 + S403A + S403B + S403C + RY401	Tuner Asy with FM Front End, YY-067	523-210-9-003
8-Track Tape Deck Asy, YY-066		523-210-9-004

CIRCUIT SYMBOL	DESCRIPTION	DYNAMSCAN PART NO.
W-070159	"A" Lead Adaptor, W-070159	026-026-9-005
RZ-004 10K ohm	Resistor, Precision Resistor, RZ-004	013-026-9-002
W-070153	Ground Wire, W-070153	191-251-3-003
426-025-9-001	Power & Speaker Card Asy, W-070193	426-025-9-001
426-028-9-001	Power & Speaker Card Asy, W-070193	426-028-9-001
426-029-9-001	Power & Speaker Card Asy, W-070193	426-029-9-001
426-028-9-002	Power & Speaker Card Asy, W-070193	426-028-9-002
426-029-9-002	Power & Speaker Card Asy, W-070193	426-029-9-002
253-085-9-001	Noise Suppression Capacitor, CZ-031	253-085-9-001
253-085-9-002	Noise Suppression Capacitor, CZ-031	253-085-9-002
253-085-9-003	Noise Suppression Capacitor, CZ-031	253-085-9-003
252-024-9-001	Bottom Cover	252-024-9-001
258-030-9-001	Deck Mounting Chassis	258-030-9-001
258-032-9-001	Balance Control Mounting Bracket	258-032-9-001
747-057-9-003	Heat Sink for RF Power Transistor	747-057-9-003
747-057-9-004	Heat Sink for Modulator Power IC	747-057-9-004
747-058-9-001	Shield Case for PLL	747-058-9-001
256-074-9-001	Shield Cover for PLL Front End	256-074-9-001
256-074-9-002	Shield Cover for PLL Front End	256-074-9-002
256-074-9-003	Shield Cover for PLL Front End	256-074-9-003
251-332-9-001	VR MTG Bracket (Rear)	251-332-9-001
251-332-9-002	VR MTG Bracket (Front)	251-332-9-002
251-333-9-001	VR MTG Bracket (Front)	251-333-9-001
253-064-9-001	Cord Clamp (for Microphone & Power)	253-064-9-001
741-099-9-002	Cord Clamp (for ANT)	741-099-9-002
251-337-9-001	Trimmer, MTG Bracket	251-337-9-001
763-096-9-001	Pointer Guide	763-096-9-001
763-096-9-002	Sub Chassis Asy	763-096-9-002
251-338-9-001	Dial Pointer Holder	251-338-9-001
253-210-9-005	Tape Slot Door Asy	253-210-9-005
251-339-9-001	VR-Back-up Bracket	251-339-9-001
251-325-9-001	VR-Back-up Bracket	251-325-9-001
251-325-9-002	VR-Back-up Bracket	251-325-9-002
251-326-9-001	Microphone Connector Bracket (Front)	251-326-9-001
251-326-9-002	Microphone Connector Bracket (Rear)	251-326-9-002
741-102-9-001	Microphone Mounting Strap	741-102-9-001
741-074-9-001	Microphone Hanger	741-074-9-001

CIRCUIT SYMBOL	DESCRIPTION	DYNAMSCAN PART NO.
R-10, 23, 46, 47	Resistor, Carbon Film 4.7K ohm ±5% 1/8W	002-108-5-472
R-2, 37, 258, 302	Resistor, Carbon Film 5.6K ohm ±5% 1/8W	002-108-5-562
R-282, 283	Resistor, Carbon Film 6.8K ohm ±5% 1/8W	002-108-5-682
R-40	Resistor, Carbon Film 8.2K ohm ±5% 1/8W	002-108-5-822
R-6, 16, 61, 219, 251, 253, 257, 269, 276	Resistor, Carbon Film 10K ohm ±5% 1/8W	002-108-5-103
R-11, 22, 31, 43, 266	Resistor, Carbon Film 18K ohm ±5% 1/8W	002-108-5-183
R-39, 228, 232, 254, 268	Resistor, Carbon Film 22K ohm ±5% 1/8W	002-108-5-223
R-28, 281, 284, 284	Resistor, Carbon Film 33K ohm ±5% 1/8W	002-108-5-333
R-24, 253, 256, 280	Resistor, Carbon Film 56K ohm ±5% 1/8W	002-108-5-563
R-44, 125, 256, 280	Resistor, Carbon Film 82K ohm ±5% 1/8W	002-108-5-823
R-19, 41, 240, 243, 255, 278, 288	Resistor, Carbon Film 100K ohm ±5% 1/8W	002-108-5-104
R-277	Resistor, Carbon Film 220K ohm ±5% 1/8W	002-108-5-224
R-241	Resistor, Carbon Film 330K ohm ±5% 1/8W	002-108-5-334
R-9	Resistor, Carbon Film 470K ohm ±5% 1/8W	002-108-5-474
R-231	Resistor, Carbon Film 2.2K ohm ±5% 1/8W	002-108-5-220
R-58	Resistor, Carbon Film 8.2K ohm ±5% 1/8W	002-108-5-821
R-48	Resistor, Carbon Film 10K ohm ±5% 1/8W	002-108-5-104
R-233	Resistor, Carbon Film 1K ohm ±5% 1/2W	002-102-5-102
R-228	Resistor, Carbon Film 1K ohm ±5% 1/2W	002-102-5-102
R-232	Resistor, Carbon Film 4.7 ohm ±5% 1/8W	002-108-5-479
R-34, 38	Resistor	

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
L-113	Coil, LA-185	066-024-9-006
L-112	Coil, LA-189	066-024-9-010
L-111	Coil, LD-051	041-064-9-001
L-110	Coil, LD-012	044-059-9-001
L-109	Coil, LC-020	044-059-9-002
L-108	Coil, LC-070	044-059-9-001
L-107	Coil, LE-008	044-032-9-001

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
R-1516	Resistor, Carbon Film 3.9K ohm 15% 1/8W	002-108-5-392
R-49,213	Resistor, Carbon Film 1.5K ohm 15% 1/8W	002-108-5-152
R-27,250,238	Resistor, Carbon Film 2.2K ohm 15% 1/8W	002-108-5-222
R-17,250,54,218,219	Resistor, Carbon Film 3.3K ohm 15% 1/8W	002-108-5-332

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
R-216,276,289,201	Resistor, Carbon Film 1.5K ohm 15% 1/8W	002-108-5-152
R-216,276,289,201	Resistor, Carbon Film 2.2K ohm 15% 1/8W	002-108-5-222
R-17,250,54,218,219	Resistor, Carbon Film 3.3K ohm 15% 1/8W	002-108-5-332
R-1516	Resistor, Carbon Film 3.9K ohm 15% 1/8W	002-108-5-392

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
R-10,23,46,47	Resistor, Carbon Film 4.7K ohm 15% 1/8W	002-108-5-472
R-2,37,258,302	Resistor, Carbon Film 5.6K ohm 15% 1/8W	002-108-5-562
R-282,283	Resistor, Carbon Film 6.8K ohm 15% 1/8W	002-108-5-682
R-40	Resistor, Carbon Film 8.2K ohm 15% 1/8W	002-108-5-822
R-6,18,61,219,251,253,257,268,276	Resistor, Carbon Film 10K ohm 15% 1/8W	002-108-5-10K
R-10,23,46,47	Resistor, Carbon Film 15K ohm 15% 1/8W	002-108-5-15K
R-11,22,31,43,268	Resistor, Carbon Film 18K ohm 15% 1/8W	002-108-5-18K
R-28,261	Resistor, Carbon Film 22K ohm 15% 1/8W	002-108-5-22K
R-32,53,56,211,284	Resistor, Carbon Film 27K ohm 15% 1/8W	002-108-5-27K
R-24,225,226,280	Resistor, Carbon Film 33K ohm 15% 1/8W	002-108-5-33K
R-44	Resistor, Carbon Film 39K ohm 15% 1/8W	002-108-5-39K
R-19,41,240,243,285,278,288	Resistor, Carbon Film 47K ohm 15% 1/8W	002-108-5-47K
R-241	Resistor, Carbon Film 56K ohm 15% 1/8W	002-108-5-56K
R-9	Resistor, Carbon Film 68K ohm 15% 1/8W	002-108-5-68K
R-231	Resistor, Carbon Film 82K ohm 15% 1/8W	002-108-5-82K
R-48	Resistor, Carbon Film 100 ohm 15% 1/8W	002-108-5-100
R-48	Resistor, Carbon Film 150 ohm 15% 1/8W	002-108-5-150
R-253	Resistor, Carbon Film 1K ohm 15% 1/2W	002-102-5-100
R-223	Resistor, Carbon Film 1 ohm 15% 1/2W	002-102-5-100
R-34,38	Resistor, Carbon Film 4.7 ohm 15% 1/8W	002-108-5-470
R-236,290	Resistor, Carbon Film 47 ohm 15% 1/8W	002-108-5-470
R-15,33,42,107,111,235	Resistor, Carbon Film 56 ohm 15% 1/8W	002-108-5-560
R-103,208,239,288	Resistor, Carbon Film 100 ohm 15% 1/8W	002-108-5-100
R-274	Resistor, Carbon Film 220 ohm 15% 1/8W	002-108-5-220
R-35	Resistor, Carbon Film 470 ohm 15% 1/8W	002-108-5-470
R-206,242,244	Resistor, Carbon Film 560 ohm 15% 1/8W	002-108-5-560
R-102,209	Resistor, Carbon Film 1K ohm 15% 1/8W	002-108-5-100
R-113,204	Resistor, Carbon Film 1.5K ohm 15% 1/8W	002-108-5-150
R-27,21,26,273	Resistor, Carbon Film 2.2K ohm 15% 1/8W	002-108-5-220
R-10,108	Resistor, Carbon Film 3.3K ohm 15% 1/8W	002-108-5-330
R-108,110	Resistor, Carbon Film 5.6K ohm 15% 1/8W	002-108-5-560
R-29,237	Resistor, Carbon Film 6.8K ohm 15% 1/8W	002-108-5-680
R-250	Resistor, Carbon Film 10K ohm 15% 1/8W	002-108-5-10K
R-202	Resistor, Carbon Film 22K ohm 15% 1/8W	002-108-5-22K
R-227	Resistor, Carbon Film 33K ohm 15% 1/8W	002-108-5-33K
R-105,109,248	Resistor, Carbon Film 56K ohm 15% 1/8W	002-108-5-56K
R-59	Resistor, Carbon Film 100K ohm 15% 1/8W	002-108-5-100
R-228	Resistor, Carbon Film 470K ohm 15% 1/8W	002-108-5-470
R-116	Resistor, Carbon Film 680K ohm 15% 1/8W	002-108-5-680
R-101	Resistor, Carbon Film 3.3K ohm 15% 1/2W	015-019-9-001
R-246	Resistor, Carbon Film 150 ohm 110%	2M

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
C-283,284	Capacitor, Tantalum, 2.2uF	027-031-9-001
C-102,103,109,110	Capacitor, Tantalum, 4.7uF	027-032-9-001
C-312	Capacitor, Tantalum, 10uF	027-031-9-002
C-49,50,308	Capacitor, Aluminum Solid, 0.22uF	027-158-9-001
C-51	Capacitor, Aluminum Solid, 0.47uF	027-158-9-002
C-51	Capacitor, Polyester Film, 470pF	022-157-9-002
C-51	Capacitor, Electrolytic, 1uF	022-157-9-002
C-256,286	Capacitor, Electrolytic, 2.2uF	022-158-9-002
C-34,46,59,62	Capacitor, Electrolytic, 4.7uF	022-157-9-003
C-248,265	Capacitor, Electrolytic, 10uF	022-157-9-004
C-35,45,106,108	Capacitor, Electrolytic, 22uF	022-163-9-001
C-104,117,251,316	Capacitor, Electrolytic, 33uF	022-157-9-006
C-42,56,118,119,123,124,302,303,291	Capacitor, Electrolytic, 47uF	022-164-9-001
C-80	Capacitor, Electrolytic, 100uF	022-164-9-002
C-58,64,69,128,129,283,287	Capacitor, Electrolytic, 100uF	022-164-9-002
C-259	Capacitor, Electrolytic, 100uF	022-164-9-002
C-294	Capacitor, Electrolytic, 220uF	022-163-9-003
C-247,286,306,307	Capacitor, Electrolytic, 330uF	022-163-9-003
C-101	Capacitor, Electrolytic, 470uF	022-163-9-004
C-122,127	Capacitor, Electrolytic, 470uF	022-163-9-004
C-259	Capacitor, Electrolytic, 1000uF	022-163-9-004
C-27,221	Capacitor, Polyester Film, 0.002uF	025-122-9-001
C-27,30,222	Capacitor, Polyester Film, 0.0022uF	025-122-9-001
C-26,31,57,61	Capacitor, Polyester Film, 0.0047uF	025-126-9-001
C-300,301	Capacitor, Polyester Film, 0.0068uF	025-122-9-003
C-287,298	Capacitor, Polyester Film, 0.01uF	025-121-9-002
C-38,105,107	Capacitor, Polyester Film, 0.012uF	025-121-9-003
C-33,54,55,63,235,284,289	Capacitor, Polyester Film, 0.022uF	025-121-9-004
C-86,37,43,288,289	Capacitor, Polyester Film, 0.047uF	025-121-9-005
C-215	Capacitor, Polyester Film, 0.068uF	025-125-9-001
C-204,224	Capacitor, Ceramic Disk, 1.5pF	020-190-9-001
C-213,285	Capacitor, Ceramic Disk, 1.5pF	020-190-9-002
C-212,216	Capacitor, Ceramic Disk, 3pF	020-190-9-003
C-211,285	Capacitor, Ceramic Disk, 3pF	020-190-9-003
C-212,216	Capacitor, Ceramic Disk, 5pF	020-190-9-005
C-211,276	Capacitor, Ceramic Disk, 5pF	020-190-9-005
C-211,276	Capacitor, Ceramic Disk, 10pF	020-190-9-006
C-211,276	Capacitor, Ceramic Disk, 15pF	020-190-9-007
C-211,276	Capacitor, Ceramic Disk, 22pF	020-190-9-008
C-211,276	Capacitor, Ceramic Disk, 33pF	020-190-9-009
C-211,276	Capacitor, Ceramic Disk, 47pF	020-190-9-010
C-211,276	Capacitor, Ceramic Disk, 68pF	020-190-9-011
C-211,276	Capacitor, Ceramic Disk, 100pF	020-190-9-012
C-211,276	Capacitor, Ceramic Disk, 150pF	020-190-9-013
C-211,276	Capacitor, Ceramic Disk, 220pF	020-190-9-014
C-211,276	Capacitor, Ceramic Disk, 330pF	020-190-9-014

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
M-401,PL-401	Meter, MT-087 Lamp Bulb	320-082-9-001
P-21,22,23	Test Point Terminal, TP-033	757-037-9-001
CR-3P	Plug Pins, PG-044	523-209-9-004
CR-3P	Plug Pins, PG-039	523-210-9-002
CR-4P	Plug Pins, PG-044	523-210-9-002
CR-4P	Plug Pins, PG-038	523-209-9-002
CR-102P	Plug 7 Pins, PG-038	523-209-9-001
CR-102P	Remote Control Microphone, MK-066	562-021-9-001
TP-11,12,13,14,15,16	Test Point Terminal, TP-029	757-033-9-001
SSA + SB6 + S7 + S8 + S9 + S10	Push Button Switch	088-039-9-001
LI-28 + LI-2C	Tuner Assy with FM Front End, YY-067	523-210-9-003
LI-28 + LI-2C	8-Track Tape Deck Assy, YY-066	523-210-9-004

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
W-0701B9	"A" Lead Adaptor, W-0701B9	426-026-9-005
FZ-004 OK ohm	Neon Suppression Resistor, FZ-004 OK ohm	01-026-9-002
W-0701B3	Power & Speaker Cord Assy, W-0701B3	191-256-9-002
W-0701B3	Power & Speaker Cord Assy, W-0701B3	426-026-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	426-026-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	763-083-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	021-062-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	426-026-9-002
W-0701B3	Power & Speaker Cord Assy, W-0701B3	258-031-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	253-085-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	252-024-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	258-032-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	251-336-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	747-057-9-003
W-0701B3	Power & Speaker Cord Assy, W-0701B3	747-058-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	256-074-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	256-074-9-002
W-0701B3	Power & Speaker Cord Assy, W-0701B3	256-074-9-003
W-0701B3	Power & Speaker Cord Assy, W-0701B3	256-074-9-004
W-0701B3	Power & Speaker Cord Assy, W-0701B3	251-332-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	251-333-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	741-101-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	253-084-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	741-089-9-002
W-0701B3	Power & Speaker Cord Assy, W-0701B3	251-337-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	763-086-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	258-033-9-002
W-0701B3	Power & Speaker Cord Assy, W-0701B3	251-338-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	523-210-9-005
W-0701B3	Power & Speaker Cord Assy, W-0701B3	251-335-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	767-051-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	251-325-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	251-326-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	741-102-9-001
W-0701B3	Power & Speaker Cord Assy, W-0701B3	741-074-9-001

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
C-202,203,205,206,207,208,228,237,238,240	Capacitor, Ceramic Disk 0.01uF	020-190-9-015
241,246,249,252,256,258,260,265,267,268,282,280,282,285,305,309,310,313,314,315,317	Capacitor, Ceramic Disk 0.02uF	020-190-9-016
C-209,210,212,213,214,216,217	Capacitor, Ceramic Disk 0.04uF	020-190-9-017
C-4,6,12,13,14,15,20,40,65	Capacitor, Ceramic Disk 0.01uF	020-190-9-021
C-24,25,66	Capacitor, Ceramic Disk 0.04uF	020-190-9-022
C-9,39,44	Capacitor, Ceramic Disk 220pF	020-190-9-019
C-41,111,112	Capacitor, Ceramic Disk 560pF	020-190-9-020
C-271	Capacitor, Ceramic Disk 70pF	020-190-9-023
C-201	Capacitor, Ceramic Disk 27pF	020-190-9-024
C-19	Capacitor, Ceramic Disk 30pF	020-190-9-025
C-18	Capacitor, Ceramic Disk 12pF	020-190-9-026
C-16	Capacitor, Ceramic Disk 15pF	020-190-9-027
C-17	Capacitor, Ceramic Disk 27pF	020-190-9-028
C-32	Capacitor, Ceramic Disk 200pF	020-190-9-029
C-5	Capacitor, Ceramic Disk 1uF	020-190-9-021
C-10	Capacitor, Ceramic Disk 2uF	020-180-9-002
C-3,28	Capacitor, Ceramic Disk 3uF	020-180-9-003
C-9	Capacitor, Ceramic Disk 4uF	020-180-9-004
C-2	Capacitor, Ceramic Disk 10pF	020-180-9-009
C-282	Capacitor, Ceramic Disk 10pF	020-181-9-008
C-11,7	Capacitor, Ceramic Disk 12pF	020-181-9-009
C-278	Capacitor, Ceramic Disk 15pF	020-186-9-001
C-29	Capacitor, Ceramic Disk 50pF	020-190-9-034
C-24	Capacitor, Ceramic Disk 100pF	020-190-9-036
C-244	Capacitor, Ceramic Disk 120pF	020-190-9-035
C-121,126,304	Capacitor, Ceramic Disk 0.2 F	020-187-9-012
C-113,114,115,116	Capacitor, Ceramic Disk 0.2 F	020-190-9-037
CC-1	Capacitor Assy, Ceramic Feed-Thru, HA-003	527-077-9-002
C-401,402,403,404,405,406	Capacitor Assy, Ceramic Feed-Thru, CZ-000	033-038-9-001

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
QX-077,10,24	Quartz Crystal, QX-077 10.24 MHz	133-014-9-001
QX-078,10	Quartz Crystal, QX-078 10.695 MHz	133-014-9-002
QX-079,36,57	Quartz Crystal, QX-079 36.57 MHz	133-014-9-003

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
U-07	Universal Trimplate	386-294-9-001
U-08	Standard Front Knob	260-142-9-001
U-09	Standard Rear Knob	751-162-9-001
U-10	Standard Front Knob	751-162-9-002
U-11	Standard Rear Knob	751-164-9-001
U-12	Front Type Shallow Front Knob	751-154-9-00