



**Consumer Response Group**

6500 W. Cortland Street \* Chicago, IL 60707 \* Phone: 773-889-8870 \* FAX: 773-622-2269

---

February 22, 2008

Page 1 of 2

# **TECHNICAL SERVICE BULLETIN**

## **10056**

**MODEL(S):** CB models 25 and 29 (all versions)

**DESCRIPTION:** Adding talkback

**ACTION:** Talkback can be easily added to these radios by installing a resistor from the sleeve of the external speaker connector to ground. See page 2 for a picture of the location.

Adding a resistor will give a fixed audio level on the talkback. Try starting with a 100 ohm resistor, and adjust as needed for the desired volume level.

If an adjustable talkback level is desired, a potentiometer can be used in place of the resistor. A 200 ohm potentiometer is recommended.

**ADJUSTMENTS:** None.

**NOTES:** None.

