

COBRA P/N	MODEL	SYMBOL	DESCRIPTION
043-015	HH300/400		Antenna, complete
271-008	HH300/400		Battery tray, complete
380-067	HH300/400		Belt Clip
380-068	HH300/400		Button, belt clip
BCC 400			Charger with AC adapter & cig. cord
771-052	HH300/400		Conn., Antenna
383-007	HH300/400		Gasket, battery case
383-008	HH300/400		Gasket, main
307-054	HH300/400	IC3	IC, NJM2070, Audio amp
307-055	HH300/400	IC7	IC, XC6204B502MR, regulator
751-040	HH300/400		Knob, vol & sql
753-031	HH300		Lens, display
753-032	HH400		Lens, display
565-022	HH300/400		Mic
008-041	HH300/400	VR1,3,5,6	Pot, semi-fixed, 10K
008-042	HH300/400	VR2	Pot, squelch
008-043	HH300/400	VR4	Pot, volume on/off
384-101	HH300/400		Rubber, channel up/dn
384-102	HH300/400		Rubber, PTT
384-103	HH300/400		Rubber, PTT inner
384-104	HH400		Rubber, Scan/Mem
384-105	HH300		Rubber, WX/DW
384-106	HH400		Rubber, WX/TRIW
580-017	HH300/400		Speaker
176-018	HH300/400	Q25	Tran., 2SK3078, Driver
176-019	HH300/400	Q24	Tran., 2SK3476, Final